

Printed: Feb 15 2024



Crimper Hose Coupling Crimp Instructions CHART NUMBER 83 REV 00

SH2 111 4200 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

*ULSAR NOVA1

PULSAR 111A

PULSAR 111FS

Hose F		Fitting Insertion Length	Die	Crimp Length (Crimp D	iameter	Dial Set	J
		mm			mm	in	<u>. 4 1 2 2 3 3 3 3 3 3 3 3</u>	
111-04 42	200	23	SH2-14	Full	16.7	0.657	2.7	
111-06 42	200	25	SH2-20	Full	20.9	0.823	0.9 _	
111-08 42	200	27	SH2-24	Full	24.2	0.953	0.2	
111-12 42	200	34	SH2-28	Full	31.8	1.252	3.8	
111-16 42	200	44	SH2-40	Full	40.6	1.598	0.6	



Crimper Hose Coupling Crimp Instructions CHART NUMBER 183 REV 00

SH2 110 4200 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

≯ UĽSA	AR IIII	CORONA	17	111111					
Hose	Ferrule		Fitting Insertion Length	Die	Crimp Length	Crimp Diar	meter	Dial Set	Ū
			mm			mm	in	• •	
110-04	4200		23	SH2-14	Full	15.7 0	.618	1.7 _	
110-06	4200		25	SH2-17	Full	19.8 0	.780	2.8 _	
110-08	4200		27	SH2-20	Full	23.3 0	917	33_	

IT69 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 179 REV 00

SH2 111 P4300 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

FULSAR NOVA1

PULSAR 111A

PULSAR 111FS

		Fitting Insertion		Crimp			Dial Set	tting
Hose	Ferrule	Length	Die	Length	Crimp Dia	meter	Approx.	Actual
		mm			mm	in		_
111-04	4300	22	SH2-14	Full	16.2 0).638	2.2 _	
111-06	4300	29	SH2-20	Full	20.9).823	0.9 _	
111-08	4300	31	SH2-24	Full	24.2 0).953	0.2 _	
111-12	4300	38	SH2-28	Full	31.8 1	1.252	3.8 _	
111-16	4300	45	SH2-40	Full	40.6 1	1.598	0.6 _	

PUL 111 00



Crimper Coupling **Crimp Instructions CHART NUMBER** 86 **REV 00** Hose 112 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the SH2 4200

fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

112CC 112

Hose	Ferrule	Fitting Insertion Length	Die	Crimp Length	Crimp D	iameter	Dial Set Approx.	J
		mm			mm	in		
112-04	4200	23	SH2-14	Full	16.8	0.661	2.8	
112-06	4200	25	SH2-20	Full	21.0	0.827	1.0 _	
112-08	4200	27	SH2-24	Full	25.0	0.984	1.0 _	
112-12	4200	34	SH2-28	Full	31.8	1.252	3.8 _	
112-16	4200	44	SH2-40	Full	40.6	1.598	0.6 _	

IT04 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 84 REV 01

SH2 4200 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

					<u> </u>		
PULSAF	? ////	NOVA 2	NO	/A 2 ICE-BI	REAKER	122A	11111
Hose	Ferrule		Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
			mm			mm in	_
122-04	4200		23	SH2-17	Full	17.8 0.701	0.8
122-06	4200		25	SH2-20	Full	22.0 0.866	2.0
122-08	4200		27	SH2-24	Full	25.5 1.004	1.5
122-10	4200		30	SH2-28	Full	28.8 1.134	0.8
122-12	4200		34	SH2-32	Full	32.1 1.264	0.1
122-16	4200		44	SH2-40	Full	41.6 1.638	1.6

IT02 01



Crimper Hose Coupling Crimp Instructions CHART NUMBER 180 REV 00

SH2 P4300 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

PULSAF		NOVA 2	NO	VA 2 ICE-BF	REAKER		122A		
Hose	Ferrule		Fitting Insertion Length	Die	Crimp Length	Crimp Di	ameter	Dial Set Approx.	•
			mm			mm	in		
122-04	4300		22	SH2-14	Full	16.4	0.646	2.4 _	
122-06	4300		29	SH2-20	Full	22.0	0.866	2.0 _	
122-08	4300		31	SH2-24	Full	25.5	1.004	1.5 _	
122-12	4300		38	SH2-32	Full	32.1	1.264	0.1 _	
122-16	4300		45	SH2-40	Full	41.6	1.638	1.6 _	

PUL 122 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 124 REV 00

SH2 114 4200 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

PULSAF	NOVA 16	CARBONITE 1	16 A	JRORA 16	NOVA 18	E EXTREME
Hose	Ferrule	Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
		mm			mm in	_
114-04	4200	23	SH2-17	Full	17.2 0.677	0.2
114-06	4200	25	SH2-20	Full	20.8 0.819	0.8
114-08	4200	27	SH2-24	Full	24.2 0.953	0.2
114-10	4200	30	SH2-28	Full	28.5 1.122	0.5
114-12	4200	34	SH2-28	Full	31.8 1.252	3.8
114-16	4200	44	SH2-40	Full	40.6 1.598	0.6

IT34 00



Crimper	Hose	Coupling		Crimp Instructions	CHART NUMBER	178	REV 00
SH2	114	P4300	One-piece	Mark the hose at a distance from the end o fitting on the hose so that the mark is even the ferrule to the Crimp Diameter given in the	with the end of the ferrule. Crim	p the enti	re length of

PULSAF	NOVA 16	CARBONITE	16 AL	JRORA 16	NOVA 16	EXTREME
Hose	Ferrule	Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
		mm			mm in	
114-04	4300	22	SH2-14	Full	16.2 0.638	2.2
114-06	4300	29	SH2-20	Full	20.8 0.819	0.8
114-08	4300	31	SH2-24	Full	24.2 0.953	0.2
114-12	4300	38	SH2-28	Full	31.8 1.252	3.8
114-16	4300	45	SH2-40	Full	40.6 1.598	0.6



Crimper Hose Coupling Crimp Instructions CHART NUMBER 151 REV 02

SH2 124 4400 One-piece

Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

PULSAR |||| NOVA 12 PLUS CARBONITE 12 PLUS AURORA 12 PLUS ||

Hose Ferrule	Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
	mm			mm in	· ·
124 PLUS - 06 4400	25	SH2-24	Full	24.0 0.945	0.0
124 PLUS-08 4400	31	SH2-24	Full	26.4 1.039	2.4
124 PLUS-10 4400	31	SH2-32	Full	32.6 1.283	0.6
124 PLUS -12 4400	34	SH2-32	Full	34.3 1.350	2.3
^{124 PLUS} -16 4400	47	SH2-40	Full	42.7 1.681	2.7
124 PLUS _20 4400	54	SH2-47	Full	49.6 1.953	2.6

IT53 02



Crimper Hose Coupling Crimp Instructions CHART NUMBER 91 REV 01

SH2 124 4400 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

PULSAR SPIRAL12

***ULSAR 124AC SPIRAL12 ARMOR**

		Fitting Insertion		Crimp			Dial Set	ting
Hose	Ferrule	Length	Die	Length	Crimp D	iameter	Approx.	Actual
		mm			mm	in		
124-06	4400	25	SH2-20	Full	23.1	0.909	3.1	
124-08	4400	31	SH2-24	Full	25.4	1.000	1.4	
124-10	4400	31	SH2-32	Full	32.6	1.283	0.6	
124-12	4400	34	SH2-32	Full	33.9	1.335	1.9	
124-16	4400	47	SH2-40	Full	41.4	1.630	1.4	

IT09 01



Crimper

Hose

Coupling

Crimp Instructions

CHART NUMBER

192 REV 01

SH2

124 XTC 4400

One-piece

Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

P UĽSAR ∭	124XTC				
Hose Ferrule	Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
	mm			mm in	
124 -06 4400 XTC	25	SH2-20	Full	23.1 0.909	3.1
124 -08 4400 XTC	31	SH2-24	Full	25.4 1.000	1.4
124 -10 4400 XTC	31	SH2-32	Full	32.6 1.283	0.6
124 -12 4400 XTC	34	SH2-32	Full	33.9 1.335	1.9
124 -16 4400 XTC	47	SH2-40	Full	41.4 1.630	1.4

IT76 01



Crimper

Hose

Coupling

Crimp Instructions

CHART NUMBER

193

REV 01

SH2

124 XTC 5000

Two-piece

Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

₩ULSAR 	124XTC	11111
roloan IIII	TETATO	

Hose Ferrule	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
			mm in	_
124 -06 5120 XTC	SH2-20	Full	23.8 0.937	3.8
124 -10 5120 XTC	SH2-28	Full	30.0 1.181	2.0
124 -12 5120 XTC	SH2-32	Full	34.6 1.362	2.6
124 -16 5120 XTC	SH2-40	Full	42.4 1.669	2.4

IT77 01



Crimper Hose Coupling Crimp Instructions CHART NUMBER 92 REV 03

SH2 136 4400 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

FULSAR SPIRAL 13

Hose Ferrule	Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
	mm			mm in	
136-12 4400	34	SH2-32	Full	35.3 1.390	3.3
136-16 4400	47	SH2-40	Full	42.0 1.654	2.0

IT10 03



Crimper Hose Coupling Crimp Instructions CHART NUMBER 160 REV 00

SH2 156 44/4600 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of

PIUSAR | NOVA 15

		Fitting Insertion		Crimp		Dial Setting
Hose	Ferrule		Die	Length	Crimp Diameter	Approx. Actual
					mm in	_
156 PLUS -12	4400	34	SH2-32	Full	35.1 1.382	3.1
156 PLUS -16	4400	47	SH2-40	Full	42.0 1.654	2.0

IT59 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 186 REV 00

SH2 124 4200 One-piece

Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

FULSAR SPIRAL12

	Fitting Insertion		Crimp		Dial Setting
Hose Ferrule	Length	Die	Length	Crimp Diameter	Approx. Actual
	mm			mm in	_
124-12 4200	34	SH2-32	Full	33.1 1.303	1.1
124-16 4200	44	SH2-40	Full	40.4 1.591	0.4

IT72 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 95 REV 02

SH2 151 4500 One-piece

Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1 mm/s 0.2 mm or + 0.004/s 0.005

the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

FULSAR 151

PULSAR 151H

			Crimp		Dial Setting
Hose	Ferrule	Die	Length	Crimp Diameter	Approx. Actual
				mm in	
151-04	4500-04	SH2-14	Knurl	16.1 0.634	2.1
151-05	4500-05	SH2-17	Full	18.3 0.720	1.3
151-06	4500-06	SH2-20	Full	20.0 0.787	0.0
151-08	4500-08	SH2-20	Full	22.9 0.902	2.9
151-10	4500-10	SH2-24	Full	26.7 1.051	2.7
151-12	4500-12	SH2-28	Full	30.8 1.213	2.8
151-16	4500-16	SH2-32	Full	35.5 1.398	3.5
151-20	4500-20	SH2-40	Full	43.5 1.713	3.5
151-24	4500-24	SH2-44	Knurl	46.8 1.843	2.8

IT12 02



Crimper Hose Coupling Crimp Instructions CHART NUMBER 176 REV 00

SH2 151 42/4400 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Telerance +0.1 mm/. 0.2 mm or +0.004/.0.00

the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

PULSAR 151 SPULSAR 151H

		Fitting Insertion		Crimp		Dial Setting
Hose	Ferrule		Die	Length	Crimp Diameter	Approx. Actual
					mm in	_
151-05	4200-04	23	SH2-17	Full	18.1 0.713	1.1
151-08	4200-06	25	SH2-20	Full	22.9 0.902	2.9
151-10	4400-08	31	SH2-28	Full	28.2 1.110	0.2
151-12	4400-10	31	SH2-28	Full	30.8 1.213	2.8

IT67 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 177 REV 00

SH2 151 5000 Two-piece Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches.

FULSAR 151

FULSAR 151H

		Crimp		Dial Setting
Hose Ferrule	Die	Length	Crimp Diameter	Approx. Actual
			mm in	
151 - 05 5200-04	SH2-17	Full	19.5 0.768	2.5
151 - 08 5120-06	SH2-20	Full	23.6 0.929	3.6
151-10 ⁵¹²⁰⁻⁰⁸	SH2-28	Full	28.6 1.126	0.6
151-12 ⁵¹²⁰⁻¹⁰	SH2-28	Full	31.8 1.252	3.8

IT68 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 87 REV 01

SH2 141 4200 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

PULSAR 141

Hose Ferrule	Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
	mm			mm in	
141-12 4200	34	SH2-32	Full	33.1 1.303	1.1
141-16 4200	44	SH2-40	Full	40.0 1.575	0.0
141-20 4400	54	SH2-47	Full	50.3 1.980	3.3

IT05 01



Crimper	Н	ose	Coupling		Crimp Instr	ructions	CHART N	NUMBER	122	REV 00
SH2	11	19	4200	Skive	fitting on the hos	at a distance from the end se so that the mark is evel e Crimp Diameter given in	n with the end o	f the ferrule. Crir	np the ent	tire length of
	*UL®	SAR	119	PULSAR	119 B	₽UĽSAR	119 Y	*ULS/	4R	119 H
			Cover Skive			Crimp			Dia	al Setting
H	ose	Ferrule	Length		Di	e Length	Crimp	Diameter	App	rox. Actua
			mm				mm	in		
11	9-04	4200	21		SH2-	14 Full	16.7	0.657	2.	.7
11	9-06	4200	21		SH2-	20 Full	20.7	0.815	0.	.7

IT33 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 146 REV 02

SH2 129G 5000 Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

PULSAR 129G

	Cover Skive		Crimp		Dial Setting	
Hose Ferru	le Length	Die	Length	Crimp Diameter	Approx. Actual	
	mm			mm in	_	
129G-06 5200	25	SH2-20	Full	20.4 0.803	0.4	
129G-06 4300	27	SH2-20	Full	21.4 0.843	1.4	
129G-06 4200	21	SH2-20	Full	20.4 0.803	0.4	
129G-08 4200	26	SH2-24	Full	25.5 1.004	1.5	
129G-08 5200	26	SH2-24	Full	24.2 0.953	0.2	

02



Crimper Hose Coupling Crimp Instructions CHART NUMBER 164 REV 00

SH2 120J 4200 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

PULSAR 120J JACK HOSE

	Fitting Insertion		Crimp		Dial Setting	
Hose Ferrule	Length	Die	Length	Crimp Diameter	Approx. Actua	<u>. </u>
	mm			mm in		_
120J-04 4200	23	SH2-14	Full	16.8 0.661	2.8	_
120J-06 4200	25	SH2-20	Full	21.0 0.827	1.0	

IT63 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 195 REV H

SH2 158 4000 Non Skive Tolerance +/- 0.1mm or +/- 0.004 inches .

PULSAR 158

			Crimp			Dial Set	tting
Hose	Ferrule	Die	Length	Crimp D	iameter	Approx.	Actual
				mm	in		
158-02	4000	SH2-6.8	Full	7.7	0.303	0.9 _	
158-03	4000	SH2-6.8	Full	8.9	0.350	2.1 _	
	4012SS-04 4042SS-04 4092SS-04	SH2-6.8	Full	8.3	0.327	1.5 _	
158-04	4000	SH2-9	Full	10.3	0.406	1.3 _	
158-05	4000	SH2-12	Full	12.2	0.480	0.2 _	
158-07	4000	SH2-14	Full	14.5	0.571	0.5 _	
158-08	4000	SH2-17	Full	17.2	0.677	0.2 _	
158-10	4000	SH2-20	Full	20.4	0.803	0.4 _	
158-14	4000	SH2-24	Full	26.6	1.047	2.6 _	

TFS-100 H



Crimper	Hose	Coupling		Crimp Instructions	CHART NUMBER	190	REV 01
SH2	158	4700	One-piece	Mark the hose at a distance from the end fitting on the hose so that the mark is ever the ferrule to the Crimp Diameter given in	n with the end of the ferrule. Crir	np the ent	ire length of

PULSAA 158

			Fitting Insertion		Crimp			Dial Set	tting
Hose	Ferrule			Die	Length	Crimp D	iameter	Approx.	Actual
						mm	in		_
158-03	4700		23	SH2-9	Knurl	11.3	0.445	2.3 _	
158-04	4700		23	SH2-12	Knurl	12.7	0.500	0.7 _	
158-06	4700		26	SH2-14	Knurl	16.0	0.630	2.0 _	
158-08	4700		29	SH2-20	Knurl	20.5	0.807	0.5 _	
158-10	4700		30	SH2-24	Knurl	25.6	1.008	1.6 _	
158-12	4700		34	SH2-28	Knurl	28.1	1.106	0.1 _	
158-14	4500	-16	45	SH2-32	Knurl	32.3	1.272	0.3 _	
158-16	4700		45	SH2-32	Knurl	35.5	1.398	3.5 _	



Crimper Hose Coupling Crimp Instructions CHART NUMBER 191 REV 01

SH2 158 5000 One-piece Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

PULSAR 158

		Fitting Insertion		Crimp			Dial Set	ting
Hose	Ferrule		Die	Length	Crimp D	iameter	Approx.	Actual
					mm	in		
158-04	5514	23	SH2-12	Full	12.7	0.500	0.7	
158-05	5514	23	SH2-14	Full	14.4	0.567	0.4	
158-06	5514	26	SH2-14	Full	16.0	0.630	2.0	
158-08	5514	29	SH2-20	Full	20.5	0.807	0.5	
158-10	5514	30	SH2-24	Full	24.8	0.976	0.8	
158-16	5514	45	SH2-32	Full	34.4	1.354	2.4	



Crimper Hose Coupling Crimp Instructions CHART NUMBER 157 REV 00

SH2 172 Non-Skive Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Televages +0.0mm/, 0.2mm or + 0.004/, 0.00

the ferrule to the Crimp Diameter given in the table. Tolerance +0.0mm/- 0.2mm or + 0.004/-0.008

FULSAR 172

FULSAR 172N FULSAR 172T

		Fitting Insertion		Crimp			Dial Set	tting
Hose Fe	errule		Die	Length	Crimp D	iameter	Approx.	Actual
					mm	in		_
172-02 47	700	13.3	SH2-9	Full	10.6	0.417	1.6 _	
172-03 47	700	21.5	SH2-12	Full	13.1	0.516	1.1 _	
172-04 47	700	23	SH2-14	Full	15.0	0.591	1.0 _	
172-06 47	700	26	SH2-17	Full	18.8	0.740	1.8 _	
172-08 47	'00	29	SH2-24	Full	24.1	0.949	0.1 _	

IT57 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 175 REV 00

SH2 4700 Non-Skive Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.0mm/- 0.2mm or + 0.004/-0.008

PULSAR 182

		Fitting Insertion		Crimp		Dial Setting
Hose	Ferrule		Die	Length	Crimp Diameter	Approx. Actual
					mm in	_
182-04	4700	23	SH2-14	Full	14.1 0.555	0.1
182-06	4700	26	SH2-17	Full	18.4 0.724	1.4
182-08	4700	29	SH2-20	Full	23.8 0.937	3.8

IT66 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 189 REV 00

SH2 173 4700 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.0mm/- 0.2mm or + 0.004/-0.008

*ULSAR 173

***ULSAR** 173T

		Fitting Insertion		Crimp			Dial Se	tting
Hose	Ferrule		Die	Length	Crimp D	iameter	Approx.	Actual
					mm	in		
173-06	4700	26	SH2-17	FULL	19.4	0.764	2.4 _	
173-08	4700	29	SH2-24	FULL	24.8	0.976	0.8 _	

PUL 173 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 96 REV 00

SH2 109 5000 Two-piece Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

*UL®	SAR	109	109CC		₽U	L'SAR	109T		
 Hose	Ferrule	Cover Skive Length	Fitting Insertion Length	Die	Crimp Length	Crimp Dia	ameter	Dial Set Approx.	· ·
		mm	mm			mm	in		
109-04	5000C		20	SH2-14	Full	15.5	0.610	1.5	
109-06	5000C		20	SH2-17	Full	18.7	0.736	1.7	
109-08	5000C		22	SH2-20	Full	22.6	0.890	2.6	

IT13 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 184 REV 00

SH2 110 5000 Two-piece Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches.

₽ULS A	AR IIII	CORONA	17	11111			
Hose	Ferrule		Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
			mm			mm in	_
110-04	5000C		20	SH2-14	Full	15.1 0.594	1.1
110-06	5000C		20	SH2-17	Full	18.7 0.736	1.7
110-08	5000C		22	SH2-20	Full	22.5 0.886	25



Crimper Hose Coupling Crimp Instructions CHART NUMBER 116 REV 00

SH2 112 5000 Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches.

_						
	₽U LSAR	112 112CC				
	Hose Ferrule	Cover Skive Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
		mm			mm in	• •
	112-04 5000C	16	SH2-14	Full	15.9 0.626	1.9
	112-06 5000C	18	SH2-17	Full	19.2 0.756	2.2
	112-08 5000C	20	SH2-20	Full	23.5 0.925	3.5
	112-12 5000C	26	SH2-28	Full	29.9 1.177	1.9
	112-16 5000C	35	SH2-36	Full	38.1 1.500	2.1



Crimper Hose Coupling Crimp Instructions CHART NUMBER 113 REV 00

SH2 111 5000 Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

*ULSAR NOVA1	₽ULSAR	111A	PULSAR	111FS
Cover			D :	

	Skive		Crimp		Dial Setting
 Hose Ferrule	Length	Die	Length	Crimp Diameter	Approx. Actual
	mm			mm in	
111-04 5000C	16	SH2-14	Full	15.9 0.626	1.9
111-06 5000C	18	SH2-17	Full	19.3 0.760	2.3
111-08 5000C	20	SH2-20	Full	23.2 0.913	3.2
111-12 5000C	26	SH2-28	Full	29.9 1.177	1.9
111-16 5000C	35	SH2-36	Full	38.1 1.500	2.1

IT27 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 111 REV 00

SH2 122 5000 Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches.

PULSAR 	NOVA 2	NOVA 2 ICE-BRE	AKER	122A	
Hose Ferrule	Cover Skive Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
	mm			mm in	
122-04 5000C	16	SH2-14	Full	16.4 0.646	2.4
122-06 5000C	18	SH2-20	Full	20.0 0.787	0.0
122-08 5000C	20	SH2-20	Full	23.8 0.937	3.8
122-12 5000C	26	SH2-28	Full	30.1 1.185	2.1
122-16 5000C	35	SH2-36	Full	38.4 1.512	2.4

IT26 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 150 REV 01

SH2 124 5000 Two-piece Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

PIUS

PULSAF	? ////	NOVA 12 PLUS	CARBONITE	12 PLUS	AURORA 12	PLUS
Hose	Ferrule	Cover Skive Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
		mm			mm in	
124 PLUS - 06	5420	25	SH2-20	Full	23.0 0.906	3.0
124 PLUS - 08	5420	27	SH2-24	Full	26.2 1.031	2.2
124 PLUS -10	5420	30	SH2-28	Full	29.0 1.142	1.0
124 PLUS -12	5420	32	SH2-32	Full	33.4 1.315	1.4
124 PLUS -16	5420	43	SH2-40	Full	41.7 1.642	1.7
124 PLUS -20	5420	44	SH2-47	Full	47.5 1.870	0.5



Crimper Hose Coupling Crimp Instructions CHART NUMBER 156 REV 00

SH2 124 5000 Two-piece Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

PI US

PULSAR ||||| NOVA 12 PLUS CARBONITE 12 PLUS AURORA 12 PLUS |||||

			Crimp		Dial Setting
Hose	Ferrule	Die	Length	Crimp Diameter	Approx. Actual
				mm in	_
124 PLUS - 06	5120	SH2-24	Full	24.1 0.949	0.1
124 PLUS -1 0	5120	SH2-28	Full	30.0 1.181	2.0
124 PLUS -12	5120	SH2-32	Full	34.6 1.362	2.6
124 PLUS -1 6	5120	SH2-40	Full	42.4 1.669	2.4
124 PLUS _2 0	5120	SH2-47	Full	50.7 1.996	3.7

IT56 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 172 REV 00

SH2 156 5000 Two-piece Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

PLUS

*ULSA	₹ ////	NOVA 15				
Hose	Ferrule	Cover Skive Length	Die	Crimp Length	Crimp Diamete	Dial Setting - Approx. Actual
		mm			mm in	_
156 PLUS -12	5420	32	SH2-32	Full	33.9 1.335	1.9
156 PLUS -16	5420	43	SH2-40	Full	40.8 1.606	0.8

IT64 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 173 REV 01

SH2 156 5000 Two-piece Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches.

PI US

PULSAR |||| NOVA 15

		Crimp		Dial Setting
Hose Ferrule	Die	Length	Crimp Diameter	Approx. Actual
			mm in	
^{156 PLUS} -12 5120	SH2-32	Full	35.1 1.382	3.1
156 PLUS-16 5120	SH2-40	Full	42.0 1.654	2.0

IT65 01



Crimper Hose Coupling Crimp Instructions CHART NUMBER 112 REV 00

SH2 G102 5000 Non Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

Hose	Ferrule	Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
		mm			mm in	
G102-06	5 5000C	18	SH2-17	Full	19.3 0.760	2.3
G102-08	3 5000C	22	SH2-20	Full	23.0 0.906	3.0
G102-12	2 5000C	28	SH2-28	Full	31.3 1.232	3.3



Crimper Hose Coupling Crimp Instructions CHART NUMBER 196 REV 00

SH2 G103 5000 Non Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

Hose	Ferrule	Fitting Insertion Length	Die	Crimp Length	Crimp Diame	Dial Settin ter Approx. A	ng .ctual
		mm			mm ir	1	
G103-06	5000C	18	SH2-17	Full	19.3 0.76	60 2.3 <u> </u>	
G103-08	5000C	20	SH2-20	Full	23.6 0.92	29 3.6	
G103-12	5000C	26	SH2-28	Full	31.0 1.22	20 3.0	



Crimper Hose Coupling Crimp Instructions CHART NUMBER 153 REV 00

SH2 114 5000 Two-piece Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches.

PUĽSAF	? ////	NOVA 16	CARBONITE 16	A	JRORA 16		NOVA 16	EXTREME	
Hose	Ferrule	Cover Skive Length		Die	Crimp Length	Crimp D)iameter	Dial Set	•
		mm				mm	in		
114-04	5000C	16	S	H2-14	Full	15.9	0.626	1.9 _	
114-06	5000C	18	S	H2-17	Full	19.1	0.752	2.1 _	
114-08	5000C	20	S	H2-20	Full	22.6	0.890	2.6	
114-10	5000C	20	S	H2-24	Full	26.7	1.051	2.7 _	
114-12	5000C	26	S	H2-28	Full	29.8	1.173	1.8 _	
114-16	5000C	35	S	H2-36	Full	37.7	1.484	1.7 _	

NOTE: Die and dial settings are approximate recommendations. Ferrules should be crimped with the largest diameter die set available to make the ridges on the finished crimp as small as possible. All crimp dimensions must be verified with a calibrated measuring device.



Crimper Hose Coupling Crimp Instructions CHART NUMBER 100 REV 00

SH2 111 5000 Non-Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

PULSAR NOVA1 PULSAR 111A PULSAR 111FS

		Fitting Insertion		Crimp		Dial Setting
Hose	Ferrule	Length	Die	Length	Crimp Diameter	Approx. Actual
		mm			mm in	
111-04	5200	23	SH2-17	Full	17.9 0.705	0.9
111-06	5200	25	SH2-20	Full	20.6 0.811	0.6
111-08	5200	27	SH2-20	Full	23.4 0.921	3.4
111-12	5200	34	SH2-28	Full	30.9 1.217	2.9
111-16	5200	44	SH2-36	Full	38.7 1.524	2.7
111-20	5200	54	SH2-47	Full	48.6 1.913	1.6

IT15 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 130 REV 00

SH2 114 5000 Two-piece Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

PULSAF	NOVA 16	CARBONITE '	16 A	URORA 16	NOVA 1	6 EXTREME
Hose	Ferrule	Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
		mm			mm in	
114-04	5200	23	SH2-17	Full	18.2 0.717	1.2
114-06	5200	25	SH2-20	Full	20.4 0.803	0.4
114-08	5200	27	SH2-20	Full	23.5 0.925	3.5
114-12	5200	34	SH2-28	Full	30.5 1.201	2.5
114-16	5200	44	SH2-36	Full	38.6 1.520	2.6
114-20	5200	54	SH2-47	Full	49.2 1.937	2.2

IT40 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 102 REV 00

SH2 112 5000 Non-Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

112CC ***ULSAR** 112 **Fitting Dial Setting** Insertion Crimp Length Length **Ferrule** Die **Crimp Diameter** Hose Approx. Actual in mm mm 112-04 5200 23 SH2-17 Full 18.2 0.717 1.2 _____ 112-06 5200 25 SH2-20 Full 20.9 0.823 112-08 5200 27 SH2-20 Full 23.5 0.925 2.5 _____ 112-12 5200 34 SH2-28 Full 30.5 1.201 2.6 _____ 112-16 5200 SH2-36 Full 38.6 1.520 44



Crimper Hose Coupling Crimp Instructions CHART NUMBER 101 REV 00

SH2 122 5000 Non-Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

PULSAR IIII	NOVA 2	NO	/A 2 ICE-BI	REAKER		122A	111111
Hose Ferru	ıle	Fitting Insertion Length	Die	Crimp Length	Crimp D)iameter	Dial Setting Approx. Actual
		mm			mm	in	
122-04 5200)	23	SH2-17	Full	19.1	0.752	2.1
122-06 5200)	25	SH2-20	Full	21.4	0.843	1.4
122-08 5200)	27	SH2-24	Full	24.5	0.965	0.5
122-12 5200)	34	SH2-28	Full	31.2	1.228	3.2
122-16 5200)	44	SH2-36	Full	39.4	1.551	3.4



Crimper Hose Coupling Crimp Instructions CHART NUMBER 105 REV 00

SH2 122 5000 Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches.

PULSAF	? ////	NOVA 2	NOVA 2 ICE	BREAKER		122A	111111
Hose	Ferrule	Cover Skive Length	Die	Crimp Length	Crimp Dia	meter	Dial Setting Approx. Actual
		mm			mm	in	_
122-04	5420	24	SH2-17	Full	17.3 0	.681	0.3
122-06	5420	25	SH2-20	Full	22.5 0	.886	2.5
122-08	5420	27	SH2-24	Full	25.8 1	.016	1.8
122-10	5420	30	SH2-28	Full	28.7 1	.130	0.7
122-12	5420	32	SH2-32	. Full	33.6 1	.323	1.6
122-16	5420	43	SH2-40	Full	41.3 1	.626	1.3
122-20	5420	44	SH2-47	. Full	49.4 1	.945	2.4

IT20 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 103 REV 02

SH2 124 5000 Two-piece Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

FULSAR SPIRAL12

***ULSAR 124AC SPIRAL12 ARMOR**

		Crimp		Dial Setting
Hose Ferrule	Die	Length	Crimp Diameter	Approx. Actual
			mm in	
124-06 5120	SH2-20	Full	23.8 0.937	3.8
124-10 5120	SH2-28	Full	30.0 1.181	2.0
124-12 5120	SH2-32	Full	34.6 1.362	2.6
124-16 5120	SH2-40	Full	42.4 1.669	2.4

IT18 02



Crimper Hose Coupling Crimp Instructions CHART NUMBER 106 REV 00

SH2 124 5000 Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

PULSAR SPIRAL12

FULSAR 124AC SPIRAL12 ARMOR

		Cover Skive		Crimp		Dial Setting
Hose	Ferrule	Length	Die	Length	Crimp Diameter	Approx. Actual
		mm			mm in	_
124-06	5420	25	SH2-20	Full	22.8 0.898	2.8
124-08	5420	27	SH2-24	Full	26.0 1.024	2.0
124-10	5420	30	SH2-28	Full	29.0 1.142	1.0
124-12	5420	32	SH2-32	Full	33.6 1.323	1.6
124-16	5420	43	SH2-40	Full	41.7 1.642	1.7
124-20	5420	44	SH2-47	Full	49.8 1.961	2.8

IT21 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 108 REV 00

SH2 136 5000 Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches.

FULSAR SPIRAL13

	Cover Skive	Crimp		Dial Setting
Hose Ferrule	Length	Die Length	Crimp Diameter	Approx. Actual
	mm		mm in	
136-12 5420	32	SH2-32 Full	34.5 1.358	2.5
136-16 5420	43	SH2-40 Full	41.5 1.634	1.5

IT23 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 110 REV 01

SH2 141 5000 Non-Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

PULSAR 141

Hose Ferrule	Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
	mm			mm in	_
141-12 5200		SH2-32	Full	33.1 1.303	1.1
141-16 5200		SH2-40	Full	41.0 1.614	1.0
141-20 5420		SH2-47	Full	49.5 1.949	2.5



Crimper Hose Coupling Crimp Instructions CHART NUMBER 109 REV 00

SH2 156 5000 Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

*ULSAR (SPIRAL15)

	Cover Skive		Crimp		Dial Setting
Hose Ferrule	Length	Die	Length	Crimp Diameter	Approx. Actual
	mm			mm in	_
156-16 5420	43	SH2-40	Full	41.6 1.638	1.6

IT24 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 187 REV 00

SH2 T101 T1000F Two-piece

PULSAR T101 MICROBORE					
Hose Ferrule	Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
	mm			mm in	_
T101-2M T1000F	9.3	SH2-6.8	Full	7.1 0.280	0.3

IT73 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 132 REV 00

SH2 172 5000 Non-Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

₱ULSAR 172

FULSAR 172N

***ULSAR** 172T

Usas		Fitting Insertion Length	D:-	Crimp Length	O-i D		Dial Set	J
Hose	Ferrule	Longui	Die	Lengui	Crimp D	iameter	Approx.	Actual
		mm			mm	in		
172-02	9700	13	SH2-9	13.0	9.6	0.378	0.6	
172-03	9000SB	19	SH2-9	18	11.4	0.449	2.4	
172-03	9700	20.2	SH2-12	19.8	12.6	0.496	0.6	
172-03	5517		SH2-9	Full	11.9	0.469	2.9	
172-04	5517		SH2-14	Full	14.4	0.567	0.4	
172-05	5517		SH2-17	Full	17.1	0.673	0.1	
172-06	5517		SH2-17	Full	18.6	0.732	1.6	
172-08	5517		SH2-20	Full	22.9	0.902	2.9 _	

TO1 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 194 REV 01

SH2 119MS 42/44/50 Non Skive

Green Line 119MS MINE SPRAY HOSE MSHA COVER

		Crimp		Dial Setting
Hose Ferrule	Die	Length	Crimp Diameter	Approx. Actual
			mm in	
119MS-16 4400	SH2-40	Full	42.2 1.661	2.2
119MS-16 4200	SH2-40	Full	40.1 1.579	0.1
119MS-16 5200	SH2-36	Full	39.4 1.551	3.4



Crimper Hose Coupling Crimp Instructions CHART NUMBER 165 REV 00

SH2 186SC 9800 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

186SC Lateral Sewer Cleaning Hose

		sertion epth		Crimp			Dial Sett	ing
Hose Ferr	rule		Die	Length C	rimp Di	ameter A	Approx.	Actual
					mm	in		
186SC-02 9800	0	12.7	SH2-9	13.2	9.4	0.370	0.4	
186SC-03 9800	0	19.0 S	SH2-12 2	22.2	12.3	0.484	0.3	
186SC-04 9800	0 2	28.5 S	SH2-14 2	27.4	14.4	0.567	0.4	
186SC-06 9800	0 3	30.4 S	SH2-17 2	27.4	17.5	0.689	0.5	
186SC-08 9800	0 3	31.8	SH2-20	31.8	22.1	0.870	2.1	

PIR1 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 166 REV 00

SH2 185SC 9800 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

185SC Sewer Cleaning Hose 3000 psi

	Insertion Depth		Crimp		Dial Setting
Hose Ferrule		Die	Length	Crimp Diameter	Approx. Actual
				mm in	_
185SC-12 9800	44.5	SH2-28	38.1	30.5 1.201	2.5
185SC-12 9800 Mender	44.0	SH2-28	38.1	30.5 1.201	2.5
185SC-16 9800 Mender	44.0	SH2-36	34.3	37.6 1.480	1.6
185SC-16 9800	54.0	SH2-36	44.5	37.6 1.480	1.6

PIR2 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 167 REV 00

SH2 184SC 9800 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

184SC Sewer Cleaning Hose 2500 psi

	Insertion Depth		Crimp		Dial Setting
Hose Ferrule		Die	Length	Crimp Diameter	Approx. Actual
				mm in	_
184SC-12 9800	44.5	SH2-28	38.1	30.5 1.201	2.5
184SC-12 9800 Mender	44.0	SH2-28	38.1	30.5 1.201	2.5
184SC-16 9800 Mender	44.0	SH2-36	34.3	37.6 1.480	1.6
184SC-16 9800	54.0	SH2-36	44.5	37.6 1.480	1.6

PIR3 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 170 REV 00

SH2 186SC 4700 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.0mm/- 0.2mm or + 0.004/-0.008

186SC Lateral Sewer Cleaning Hose

	Insertion Depth		Crimp		Dial Setting
Hose Ferrule		Die	Length	Crimp Diameter	Approx. Actual
				mm in	
186SC-03 4700	22.0	SH2-12		13.6 0.535	1.6
186SC-04 4700	23.2	SH2-14		15.2 0.598	1.2
186SC-06 4700	25.5	SH2-17		19.4 0.764	2.4
186SC-08 4700	29.0	SH2-24		24.5 0.965	0.5

PIR4 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 134 REV 0

SH2 173 5000 Non-Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

FULSAR 173

*ULSAR 173T

		Crimp		Dial Setting
Hose Ferrule	Die	Length	Crimp Diameter	Approx. Actual
			mm in	
173-04 5517	SH2-14	Full	14.5 0.571	0.5
173-06 5517	SH2-17	Full	18.8 0.740	1.8
173-08 5518	SH2-24	Full	25.0 0.984	1.0

TO3 0



Crimper Hose Coupling Crimp Instructions CHART NUMBER 133 REV 0

SH2 182 5000 Non-Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

PULSAR 182 FULSAR 182NY

		Crimp		Dial Setting
Hose Ferrule	Die	Length	Crimp Diameter	Approx. Actual
			mm in	_
182-04 5517	SH2-14	Full	14.1 0.555	0.1
182-06 5517	SH2-17	Full	18.2 0.717	1.2
182-08 5517	SH2-20	Full	22.6 0.890	2.6
182-12 5517	SH2-28	Full	29.8 1.173	1.8

TO2 0



Crimper	Hose	Coupling		Crimp Instructions	CHART NUMBER	181	REV 0
SH2	111	4500	One-piece	Mark the hose at a distance from the end of fitting on the hose so that the mark is even the ferrule to the Crimp Diameter given in the second	with the end of the ferrule. Crin	np the ent	ire length of

*UL'S	SAR 1	11-03					
Hose	Ferrule	Crimp Insert Size	Fitting Insertion	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
111-03	4500	-04	19	SH2-14	Full	mm in 14.8 0.583	0.8



Crimper Hose Coupling Crimp Instructions CHART NUMBER 52 REV 0

SH2 111 9000SB Skive Tolerance +/- 0.1mm or +/- 0.004 inches .

PULSAR 111-03									
Hose Ferrule	Cover Skive Length	Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual			
	mm	mm			mm in	_			
111-03 9000SB	19		SH2-9	17mm	11.6 0.457	2.6			



Crimper Hose Coupling Crimp Instructions CHART NUMBER 88 REV 00

SH2 111 4400 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

*ULSAR

NOVA1

PULSAR 111A

PULSAR 111FS

Hose	Ferrule	Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
		mm			mm in	
111-06	4400	25	SH2-20	Full	21.7 0.854	1.7
111-08	4400	31	SH2-20	Full	23.8 0.937	3.8
111-12	4400	34	SH2-32	Full	33.0 1.299	1.0
111-16	4400	47	SH2-40	Full	41.3 1.626	1.3

IT06 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 90 REV 01

SH2 112 4400 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

₽ULSAR

112

112CC

Hose Ferrule	Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
	mm			mm in	
112-06 4400	25	SH2-20	Full	21.7 0.854	1.7
112-08 4400	31	SH2-24	Full	24.0 0.945	0.0
112-10 4400	31	SH2-28	Full	31.1 1.224	3.1
112-12 4400	34	SH2-32	Full	33.0 1.299	1.0
112-16 4400	47	SH2-40	Full	40.7 1.602	0.7



Crimper Hose Coupling Crimp Instructions CHART NUMBER 131 REV 00

SH2 114 4400 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

₽U LSAF	? NOVA 16	CARBONITE 1	16 A	JRORA 16	NOVA 16	EXTREME
Hose	Ferrule	Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
		mm			mm in	_
114-06	4400	25	SH2-20	Full	22.1 0.870	2.1
114-08	4400	31	SH2-24	Full	24.0 0.945	0.0
114-10	4400	31	SH2-28	Full	31.1 1.224	3.1
114-12	4400	34	SH2-32	Full	33.0 1.299	1.0
114-16	4400	47	SH2-40	Full	40.7 1.602	0.7
114-20	4400	54	SH2-47	Full	50.6 1.992	3.6

NOTE: Die and dial settings are approximate recommendations. Ferrules should be crimped with the largest diameter die set available to make the ridges on the finished crimp as small as possible. All crimp dimensions must be verified with a calibrated measuring device.



Crimper Hose Coupling Crimp Instructions CHART NUMBER 89 REV 00

SH2 122 4400 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

PUĽSAF	? ////	NOVA 2	NO	VA 2 ICE-BI	REAKER	122A	
Hose	Ferrule		Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
			mm			mm in	
122-06	4400		25	SH2-20	Full	22.8 0.898	2.8
122-08	4400		31	SH2-24	Full	24.9 0.980	0.9
122-10	4400		31	SH2-32	Full	32.2 1.268	0.2
122-12	4400		34	SH2-32	Full	34.1 1.343	2.1
122-16	4400		47	SH2-40	Full	42.3 1.665	2.3

IT07 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 114 REV 00

SH2 119 5000 Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

PULSAR 119 PULSAR 119 B PULSAR 119 Y PULSAR 119 H

		Cover Skive		Crimp	Dial Setting	
Hose	Ferrule	Length	Die	Length	Crimp Diameter	Approx. Actual
		mm			mm in	
119-04	5200	22	SH2-17	Full	17.9 0.705	0.9
119-04	5000C	16	SH2-14	Full	15.9 0.626	1.9
119-06	5200	25	SH2-20	Full	20.1 0.791	0.1
119-06	5000C	18	SH2-17	Full	18.7 0.736	1.7
119-08	5000C	20	SH2-20	Full	23.2 0.913	3.2
119-08	5200	25	SH2-20	Full	23.4 0.921	3.4

IT28 00 the largest diam



Crimper	Hose	Coupling		Crimp Instructions	CHART NUMBER	148	REV 00
SH2	124 PLUS	9600	One-piece	Cover must be removed before the fittings of thread end of fitting uncrimped, crimp only to diameter tolerance +/- 0.1mm.			

#ULSAR	NOVA 12 PLUS	CARBONITE 1	2 PLUS	AURORA 12	PLUS
Hose Ferrule	Cover Skive Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
	mm			mm in	
124 PLUS-12 9600	46	SH2-32	Knurl	32.2 1.268	0.2
124 PLUS-16 9600	50	SH2-40	Knurl	40.1 1.579	0.1
124 PLUS-20 9600	54	SH2-47	Knurl	48.0 1.890	1.0

IT50 00



Crimper

CRIMP SPECIFICATIONS

Hose Coupling Crimp Instructions CHART NUMBER 135 REV 00

SH2 124 9600 One-piece Cover must be removed before the fittings can be attached. Leave a section of ferrule nearest thread end of fitting uncrimped, crimp only to the position described in "Crimp Length". Crimp diameter tolerance +/- 0.1mm.

FULSAR SPIRAL12

*ULSAR 124AC SPIRAL12 ARMOR

Hose	Ferrule	Cover Skive Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
		mm			mm in	_
124-12	9600	46	SH2-32	Knurl	33.1 1.303	1.1
124-16	9600	50	SH2-40	Knurl	40.9 1.610	0.9
124-20	9600	54	SH2-47	Knurl	50.0 1.969	3.0

IT42 00



PLUS

CRIMP SPECIFICATIONS

Coupling Crimper **Crimp Instructions CHART NUMBER** 149 REV 00 Hose

Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008 inches . 124 8000 SH2 Interlock

PUĽSAR	NOVA 12 PLUS	CARBONITE 12 PLUS	AURORA 12 PLUS	
	Cover Tube Skive Skive	Crimp	Dial Set	ting

Hose	Ferrule	Cover Skive Length	Tube Skive Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
		mm	mm			mm in	_
124 PLUS -12	8640	52	15	SH2-32	Full	33.8 1.331	1.8
124 PLUS -1 6	8640	65	17	SH2-40	Full	40.9 1.610	0.9
124 PLUS -20	8640	74	21.5	SH2-47	Full	50.2 1.976	3.2



Crimper	Hose	Coupling		Crimp Instructions	CHART NUMBER	162	REV 00
SH2	156 PLUS	9600	One-piece	Cover must be removed before the fittings can be attached. Leave a section of ferrule nearest thread end of fitting uncrimped, crimp only to the position described in "Crimp Length". Crimp diameter tolerance +/- 0.1mm.			

PULSAR III	NOVA 15		
Hose Ferrule	Cover Skive Length	Crimp Die Length Crimp Diameter	Dial Setting Approx. Actual
	mm	mm in	_
156 PLUS-12 9600	46	SH2-32 Knurl 32.2 1.268	0.2
156 PLUS-16 9600	50	SH2-40 Knurl 40.5 1.594	0.5

IT61 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 137 REV 00

SH2 156 One-piece Cover must be removed before the fittings can be attached. Leave a section of ferrule nearest thread end of fitting uncrimped,crimp only to the position described in "Crimp Length". Crimp diameter tolerance +/- 0.1mm.

*ULSAR (SPIRALIS)

		Cover Skive		Crimp		
Hose	Ferrule	Length	Die	Length	Crimp Diameter	Approx. Actual
		mm			mm in	
156-12	9600	46	SH2-32	Knurl	32.2 1.268	0.2
156-16	9600	50	SH2-40	Knurl	40.5 1.594	0.5

IT44 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 129 REV 00

SH2 156 8600 Interlock Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008 inches .

*ULSAR (SPIRAL15)

Cover Tube

		Skive	Skive		Crimp			
Hose	Ferrule	Length	Length	Die	Length	Crimp Diameter	Approx. Actual	
		mm	mm			mm in	_	
156-16	8640	65	17	SH2-40	Full	42.0 1.654	2.0	

IT39 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 136 REV 00

SH2 136 One-piece Cover must be removed before the fittings can be attached. Leave a section of ferrule nearest thread end of fitting uncrimped,crimp only to the position described in "Crimp Length". Crimp diameter tolerance +/- 0.1mm.

FULSAR SPIRAL13

		Cover Skive		Crimp		Dial Setting
Hos	e Ferrule	Length	Die	Length	Crimp Diameter	Approx. Actual
		mm			mm in	
136-	12 9600	46	SH2-32	Knurl	33.4 1.315	1.4
136-	16 9600	50	SH2-40	Knurl	41.0 1.614	1.0

IT43 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 128 REV 00

SH2 136 8600 Interlock Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008 inches .

PULSAR SPIRAL13

		Cover Skive	Tube Skive	C	Crimp		Dial Se	tting
 Hose	Ferrule	Length	Length	Die Le	ength Crimp	Diameter	Approx.	Actual
		mm	mm		mm	in		_
136-12	8640	52	15	SH2-32 Fu	ıll 34.1	1.343	2.1 _	
136-16	8640	65	17	SH2-40 Fu	ıll 42.5	1.673	2.5 _	

IT38 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 142 REV 00

SH2 153 8400 Interlock Tolerance +/- 0.1mm or +/- 0.004 inches .

FULSAR 153 WATER BLAST

Hose Ferrule	Cover Skive length	Tube Skive Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
	mm	mm			mm in	_
153-12 8404	43	17	SH2-36	Full	37.0 1.457	1.0
153-16 8404	47	21	SH2-40	Full	43.8 1.724	3.8



Crimper Hose Coupling Crimp Instructions CHART NUMBER 80 REV 00

SH2 154 8400 Interlock Tolerance +/- 0.1mm or +/- 0.004 inches .

PULSAR '	154 WATE	R BLAST			
Hose Ferrule	Cover Skive length	Tube Skive Length	Crim Die Leng	•	Dial Setting Approx. Actual
	mm	mm		mm in	_
154-08 8404	34	17	SH2-28 Full	28 7 1 130	0.7



Crimper Hose Coupling Crimp Instructions CHART NUMBER 143 REV 00

SH2 155 8500 Interlock Tolerance +/- 0.1mm or +/- 0.004 inches .

PULSAR 155 WATER BLAST

		Cover Skive	e Skive		Crimp		Dial Setting	
Hose	Ferrule	length	Length	Die	Length	Crimp Diameter	Approx. Actual	
		mm	mm			mm in	_	
155-08	8506	35	17	SH2-32	Full	32.5 1.280	0.5	



Crimper Hose Coupling Crimp Instructions CHART NUMBER 152 REV 00

SH2 653 4400 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

FULSAR 653 B.O.P HOSE MSHA API16D

A note on crimping BOP hose:

Blow Out Preventer hoses must be assembled with FG-firejacket sleeve and BOP over ferrule, according to Pulsar Hydraulics Ltd. Assembly Instructions in order to achieve API 16D flame specification.

Hose	Ferrule	Cover Skive Length	Over Ferrule Crimp	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
		mm				mm in	_
653-06	4400	26	34	SH2-20	Full	22.8 0.898	2.8
653-08	4400	33	36	SH2-24	Full	24.9 0.980	0.9
653-12	4400	38	43	SH2-32	Full	34.1 1.343	2.1
653-16	4400	49	52	SH2-40	Full	42.3 1.665	2.3

IT54 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 127 REV 00

SH2 115 8600 Interlock Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008 inches .

PULSAR 115

Hose	Ferrule	Cover Skive Length	Tube Skive Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
		mm	mm			mm in	_
115-12	8640	52	15	SH2-32	Full	33.7 1.327	1.7
115-16	8640	65	17	SH2-40	Full	42.0 1.654	2.0
115-20	8640	74	21.5	SH2-47	Full	50.5 1.988	3.5

NOTE: Die and dial settings are approximate recommendations. Ferrules should be crimped with the largest diameter die set available to make the ridges on the finished crimp as small as possible. All crimp dimensions must be verified with a calibrated measuring device.

IT37 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 138 REV 00

SH2 115 9600 One-piece Cover must be removed before the fittings can be attached. Leave a section of ferrule nearest thread end of fitting uncrimped,crimp only to the position described in "Crimp Length". Crimp diameter tolerance +/- 0.1mm.

PULSAR 115

Hose	Ferrule	Cover Skive Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
		mm			mm in	
115-12 9	9600	46	SH2-32	Knurl	32.4 1.276	0.4
115-16 9	9600	50	SH2-40	Knurl	40.5 1.594	0.5
115-20 9	9600	54	SH2-47	Knurl	48.0 1.890	1.0

IT45 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 104 REV 00

SH2 115 5000 Non-Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

PULSAR 115

Hos	se Ferrule	Cover Skive Length	Die	Crimp Lengt		Dial Setting er Approx. Actua	<u>al</u>
		mm			mm in		_
115	-06 5120		SH2-20) Full	23.6 0.929	3.6	_
115	-10 5120	27	SH2-28	3 Full	31.0 1.220	3.0	_
115	-12 5120		SH2-32	2 Full	34.7 1.366	S 2.7	_
115	-16 5120		SH2-40) Full	42.1 1.657	z 2.1	_

NOTE: Die and dial settings are approximate recommendations. Ferrules should be crimped with the largest diameter die set available to make the ridges on the finished crimp as small as possible. All crimp dimensions must be verified with a calibrated measuring device.

IT19 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 107 REV 00

SH2 115 5000 Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches.

PULSAR 115

Hose Fe	Cover Skive rrule Length	Die	Crimp Length C	Crimp D)iameter	Dial Set Approx.	•
	mm			mm	in		
115-06 542	20 25	SH2-20	Full	22.8	0.898	2.8	
115-08 542	20 27	SH2-24	Full	26.0	1.024	2.0	
115-12 542	20 32	SH2-32	Full	34.3	1.350	2.3	
115-16 542	20 43	SH2-40	Full	41.6	1.638	1.6	
115-20 542	20 44	SH2-47	Full	48.0	1.890	1.0	

IT22 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 93 REV 01

SH2 115 4400 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

PULSAR 115

Hose	Ferrule	Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
		mm			mm in	_
115-0	06 4400	25	SH2-20	Full	23.4 0.921	3.4
115-1	16 4400	47	SH2-40	Full	41.4 1.630	1.4
115-2	20 4400	54	SH2-47	Full	50.1 1.972	3.1

01 the

Printed: 15-Feb-24

IT11



Crimper Hose Coupling Crimp Instructions CHART NUMBER 94 REV 00

SH2 115 4400 One-piece Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

PULSAR 115

Hose	Ferrule	Cover Skive Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
		mm			mm in	
115-08	4400	27	SH2-24	Full	25.4 1.000	1.4
115-10	4400	27	SH2-32	e Full	34.0 1.339	2.0
115-12	4400	33	SH2-32	. Full	35.0 1.378	3.0

IT11A 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 145 REV 01

SH2 113 5000 Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches.

₽ UĽSAR 1	113				
Hose Ferrule	Cover Skive Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
	mm			mm in	_
113-08 5420	27	SH2-24	Full	26.1 1.028	2.1

IT48 01



Crimper Hose Coupling Crimp Instructions CHART NUMBER 68 REV 01

SH2 132 5000 Non-Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

PULSAR 132

		Crimp		Dial Setting
Hose Ferrule	Die	Length	Crimp Diameter	Approx. Actual
			mm in	
132-04 5503	SH2-17	Full	17.7 0.697	0.7
132-05 5503	SH2-20	Full	21.5 0.846	1.5
132-06 5503	SH2-20	Full	20.7 0.815	0.7
132-08 5503	SH2-24	Full	25.7 1.012	1.7
132-10 5503	SH2-28	Full	30.7 1.209	2.7
132-12 5503	SH2-32	Full	34.8 1.370	2.8
132-16 5503	SH2-40	Full	42.6 1.677	2.6
132-20 5503	SH2-44	Full	46.6 1.835	2.6

15-Feb-24



Crimper Hose Coupling Crimp Instructions CHART NUMBER 59 REV 07

SH2 151 5000 Non-Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

*ULS	AR 1	51		^p ULSA	IR 151H	
Hose	Ferrule	Crimp Insert Size	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
					mm in	
151-04	5503-03	-03	SH2-14	Full	15.5 0.610	1.5
151-05	5503-04	-04	SH2-17	7 Full	17.4 0.685	0.4
151-06	5503-05	-05	SH2-20) Full	20.8 0.819	0.8
151-08	5503-06	-06	SH2-20) Full	20.0 0.787	0.0
151-10	5503-08	-08	SH2-24	Full	24.9 0.980	0.9
151-12	5503-10	-10	SH2-28	B Full	30.4 1.197	2.4
151-16	5503-12	-14	SH2-32	2 Full	34.8 1.370	2.8
151-20	5503-16	-18	SH2-44	Full	44.1 1.736	0.1
151-24	5503-20	-22	SH2-47	' Full	47.2 1.858	0.2



Crimper Hose Coupling Crimp Instructions CHART NUMBER 67 REV 02

SH2 141 5000 Non-Skive Tolerance + 0.1/-0.2mm or + 0.004/-0.008 inches .

PULSAR 141

		Crimp		Dial Setting
Hose Ferrule	Die	Length	Crimp Diameter	Approx. Actual
			mm in	-
141-12 5503	SH2-32	Full	33.0 1.299	1.0
141-16 5503	SH2-40	Full	41.1 1.618	1.1
141-20 5503	SH2-44	Full	46.0 1.811	2.0



170-04 9700

CRIMP SPECIFICATIONS

13.8 0.543

1.8 _____

Crimper Hose Coupling Crimp Instructions CHART NUMBER 48 REV 00

SH2 170 9700 Non-Skive Leave a section of ferrule nearest thread end of fitting uncrimped, crimp only to the position described in "Crimp Length". Crimp diameter tolerance +/- 0.1mm.

24

PULSA	AR 170					
Hose	Ferrule	Fitting Insertion Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
		mm			mm in	

SH2-12

Knurl

PUL170 00



Crimper Hose Coupling Crimp Instructions CHART NUMBER 70 REV 03

SH2 136 One Piece

Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008

PULSAR SPIRAL 13

Hara Ermila	Fitting Insertion Length	D:	Crimp	Oriena Diamatan	Dial Setting
Hose Ferrule	Longui	Die	Length	Crimp Diameter	Approx. Actual
	mm			mm in	
136-12 9500	49	SH2-36	Full	37.3 1.469	1.3
136-16 9500	56	SH2-40	Full	43.9 1.728	3.9

15-Feb-24



Crimper	Hose	Coupling		Crimp Instructions	CHART NUMBER	71	REV 01
SH2	115	9500	One-pieceN	Mark the hose at a distance from the end of itting on the hose so that the mark is even the ferrule to the Crimp Diameter given in the	with the end of the ferrule. Crim	np the enti	re length of

PULSAR 115

	Fitting Insertion		Crimp		Dial Setting
Hose Ferrule	Length	Die	Length	Crimp Diameter	Approx. Actual
	mm			mm in	_
115-12 9500	49	SH2-36	Full	37.0 1.457	1.0
115-16 9500	56	SH2-40	Full	43.9 1.728	3.9



Crimper Hose Coupling Crimp Instructions CHART NUMBER 163 REV 00

SH2 156 8600 Interlock Tolerance +0.1mm/- 0.2mm or + 0.004/-0.008 inches .

PLUS

P ULSAI	7 ////	NOVA	15				
Hose	Ferrule	Cover Skive Length	Tube Skive Length	Die	Crimp Length	Crimp Diameter	Dial Setting Approx. Actual
		mm	mm			mm in	
156 PLUS -12	8640	52	15	SH2-32	Full	33.7 1.327	1.7
156 PLUS -1 6	8640	65	17	SH2-40	Full	41.2 1.622	1.2

IT62 00