

**Crimper**    **Hose**    **Coupling**    **Crimp Instructions**    **CHART NUMBER**    **49**    **REV 02**

**K501**    **111**    **9200**    **One-Piece**    Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +/- 0.1 mm or +/- 0.004 inches .

Hose	Ferrule	Fitting Insertion Length	Die	Crimp Position	Crimp Length	Crimp Diameter		Dial Setting	
						mm	in	Approx.	Actual
111-04	9200	20	0.600	FLUSH	FULL	16.9	0.665	70	_____
		Alternate	0.500						63
111-06	9200	21	0.750	FLUSH	FULL	20.6	0.811	71	_____
		Alternate							
111-08	9200	26	0.915	FLUSH	FULL	23.7	0.933	76	_____
		Alternate	0.750						61

**Crimper**    **Hose**    **Coupling**    **Crimp Instructions**    **CHART NUMBER**    **40**    **REV 06**

**K501**    **111**    **9400**    **One-Piece**    Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +/- 0.1 mm or +/- 0.004 inches .

Hose	Ferrule	Fitting Insertion Length	Die	Crimp Position	Crimp Length	Crimp Diameter		Dial Setting	
						mm	in	Approx.	Actual
111-10	9400	29	1.050	HIT TWICE	FULL	30.8	1.213	65	_____
		Alternate							
111-12	9400	32	1.275	BELOW 1/2"	FULL	35.2	1.386	68	_____
		Alternate							
111-16	9400	39	1.550	FLUSH	FULL	43.1	1.697	65	_____
		Alternate							

**Crimper**    **Hose**    **Coupling**    **Crimp Instructions**    **CHART NUMBER**    **50**    **REV 02**

**K501**    **122**    **9200**    **One-Piece**    Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +/- 0.1 mm or +/- 0.004 inches .

Hose	Ferrule	Fitting Insertion Length	Die	Crimp Position	Crimp Length	Crimp Diameter		Dial Setting	
						mm	in	Approx.	Actual
122-04	9200	20	0.600	FLUSH	FULL	17.7	0.697	67	_____
		Alternate	0.500						60
122-06	9200	21	0.750	FLUSH	FULL	21.5	0.846	69	_____
		Alternate							
122-08	9200	25	0.915	FLUSH	FULL	24.6	0.969	73	_____
		Alternate	0.750						59

**Crimper**    **Hose**    **Coupling**    **Crimp Instructions**    **CHART NUMBER**    **57**    **REV 02**

**K501**    **122**    **9400**    **One Piece**    Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +/- 0.1 mm or +/- 0.004 inches .

Hose	Ferrule	Fitting Insertion Length	Die	Crimp Position	Crimp Length	Crimp Diameter		Dial Setting		
						mm	in	Approx.	Actual	
122-06	9400	21	0.915	BELOW 1/4	FULL	24.0	0.945	75	_____	
		Alternate								
122-08	9400	25	0.915	FLUSH	FULL	27.9	1.098	65	_____	
		Alternate		1.050					74	
122-10	9400	29	1.050	HIT TWICE	FULL	31.5	1.240	63	_____	
		Alternate								
122-12	9400	32	1.275	BELOW 1/2	FULL	35.9	1.413	66	_____	
		Alternate								
122-16	9400	39	1.550	FLUSH	FULL	43.7	1.720	64	_____	
		Alternate								

**Crimper**    **Hose**    **Coupling**    **Crimp Instructions**    **CHART NUMBER**    **42**    **REV 07**

**K501**    **124**    **9400**    **One-Piece**    Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +/- 0.1 mm or +/- 0.004 inches .

Hose	Ferrule	Fitting Insertion Length	Die	Crimp Position	Crimp Length	Crimp Diameter		Dial Setting	
						mm	in	Approx.	Actual
124-06	9400	21	0.915	BELOW 1/4	FULL	24.4	0.961	74	_____
		Alternate							
124-08	9400	26	0.915	FLUSH	FULL	28.5	1.122	63	_____
		Alternate		1.050					
124-10	9400	29	1.050	HIT TWICE	FULL	32.7	1.287	59	_____
		Alternate							
124-12	9400	32	1.275	BELOW 1/2	FULL	36.3	1.429	65	_____
		Alternate							

**Crimper**    **Hose**    **Coupling**    **Crimp Instructions**    **CHART NUMBER**    **41**    **REV 06**

**K501**    **122**    **9400**    **One-Piece**    Mark the hose at a distance from the end of the hose equal to the "Insertion Length". Install the fitting on the hose so that the mark is even with the end of the ferrule. Crimp the entire length of the ferrule to the Crimp Diameter given in the table. Tolerance +/- 0.1 mm or +/- 0.004 inches .

Hose	Ferrule	Fitting Insertion Length	Die	Crimp Position	Crimp Length	Crimp Diameter		Dial Setting	
						mm	in	Approx.	Actual
122-10	9400	29	1.050	HIT TWICE	FULL	31.5	1.240	63	_____
		Alternate							
122-12	9400	32	1.275	BELOW 1/2	FULL	35.9	1.413	66	_____
		Alternate							
122-16	9400	39	1.550	FLUSH	FULL	43.7	1.720	64	_____
		Alternate							

---

Crimper    Hose    Coupling

Crimp Instructions

CHART NUMBER

41

REV 06